




Adhesive Application Solutions | ISO 9001 certified

EQUITY-C

SLOT DIE APPLICATOR

Technical Documentation, No. 40-51, Rev.8.23
English – Original Instructions



Information about this manual



Read all instructions before operating this equipment!

It is the customer’s responsibility to have all operators and service personnel read and understand this information. Contact your ITW Dynatec customer service representative for additional copies.



NOTICE:

Please be sure to include the serial number of your application system each time you order replacement parts and/or supplies. This will enable us to send you the correct items that you need.

NOTICE:

Most common screws, nuts and washers called out in the manual are not for sale and they can be obtained locally at your hardware Store. Specialty fasteners are available by contacting ITW Dynatec’s Customer Service.

ITW Dynatec Service Parts Direct Dial: 1-800-538-9540
 ITW Dynatec Technical Service Direct Dial: 1-800-654-6711

ITW Dynatec Service Parts and Technical Service:

AMERICAS	EUROPE, MIDDLE EAST & AFRICA	ASIA PACIFIC	
ITW Dynatec 31 Volunteer Drive Hendersonville, TN 37075 USA Tel. +1.615.824.3634 info@itwdynatec.com service@itwdynatec.com	ITW Dynatec Industriestrasse 28 40822 Mettmann Germany Tel. +49.2104.915.0 info@itwdynatec.de service@itwdynatec.de	ITW Dynatec No.2 Anzhi Street SIP, Suzhou, 215122 China Tel. +86.512.6289.0620 info@itwdynatec.cn service@itwdynatec.cn	ITW Dynatec Tsukimura Building 5th Floor 26-11, Nishikamata 7-chome Ota-ku, Tokyo 144-0051, Japan Tel. +81.3.5703.5501 info@itwdynatec.co.jp service@itwdynatec.co.jp

Index

Information about this manual	2
Index	3
Chapter 1 Declaration of Incorporation / Conformity	7
Chapter 2 Safety Instructions.....	9
2.1 General Considerations.....	9
2.2 Warning Labels	9
2.3 Safety Symbols in this Manual	10
2.4 Safe Installation and Operation	11
2.5 Explosion/ Fire Hazard	12
2.6 Use of PUR (Polyurethane) Adhesives	12
2.7 Eye Protection & Protective Clothing	12
2.8 Electrical.....	13
2.9 Lockout/ Tagout.....	13
2.10 High Temperatures.....	13
2.11 High Pressure.....	14
2.12 Protective Covers.....	14
2.13 Servicing, maintenance	15
2.14 Cleaning Recommendation	15
2.15 Secure transport.....	15
2.16 Treatment for Burns from Hot Melt Adhesives	16
2.17 Measures in case of fire	16
2.18 Keep attention to environmental protection standards.....	17
Chapter 3 Description and Technical Specs	19
3.1 Applicable Safety Regulations	19
3.1.1 Intended Use	19
3.1.2 Unintended Use, Examples	19
3.1.3 Residual Risks	19
3.1.4 Technical changes	20
3.1.5 Using foreign components	20
3.1.6 Start-up operation	20
3.2 Description Equity-C Slot Die Applicator.....	21
3.2.1 Description	21
3.2.2 Specifications	22
3.2.3 Model Designation Guide for Equity-C Applicator	23
3.3 Solenoid Air Programs	24
3.4 Standard Configurations.....	25
3.5 Dimensions.....	26
3.5.1 Equity-C 100mm	26
3.5.2 Equity-C 200mm	27
3.5.3 Equity-C 300mm	28
3.5.4 Equity-C 400mm	29
3.5.5 Equity-C 500mm	30
3.5.6 Equity-C 600mm	31
3.5.7 Equity-C 700mm	32
3.5.8 Equity-C 800mm	33
3.5.9 Equity-C 900mm	34
Chapter 4 Installation & Start-up Operation.....	35
4.1 Conditions for installation and mounting	35
4.2 Installation	36
4.3 Quality of compressed Air	39
4.4 Advices for the start-up operation	40

4.5 Start-up operation, in general.....	41
4.5 Shut Down Procedure	44
Chapter 5 Maintenance and Repair Notes	45
5.1 Security advices for maintenance and repair.....	45
5.1.1 Cleaning Recommendation.....	46
5.1.2 Equipment Preparation for Maintenance & Repair	46
5.1.3 Re-Assembly Procedures and General Cautions	47
5.2 Maintenance plan	48
5.3 Module Replacement	49
5.4 Replacement of the Filter in Optional Filter Block.....	50
5.5 Changing, Cleaning or Cutting New Shims.....	52
5.5.1 Disassembly of Die Lip Set (To Change or Clean Shim).....	52
5.5.2 Cleaning a Shim.....	53
5.5.3 Cutting a New Shim	53
5.5.4 Reassembly	54
Chapter 6 Troubleshooting.....	55
6.1 Troubleshooting In General.....	55
6.2 Troubleshooting Guide	56
6.3 Testing of Heater Cartridge or Temperature Sensor	58
6.4 Replacement of Heater Cartridge or Sensor.....	60
Chapter 7 Ordering Guide.....	61
7.1 Slot Die Head Heater Cartridges.....	61
7.2 RTD Temperature Sensors	61
7.3 Multi-bead Nozzle.....	61
7.4 Extension Cable Assemblies.....	61
7.5 Filter Kits	62
7.6 Recommended Spare Parts.....	63
Chapter 8 Component Illustrations and Bill of Materials	65
8.1 Standard Equity-C Applicator and Components	66
8.1.1 Equity-C Applicator 100mm	66
8.1.2 Equity-C Applicator 200mm	68
8.1.3 Equity-C Multiple Manifold (assorted) Assemblies	70
8.1.4 Filter Block Assembly, APEX, PN 111518.....	72
8.2 Extruders (Slot Nozzles).....	73
8.2.1 Standard Extruder Assemblies Table	73
8.2.2 Eagle-Beak Style Extruder Assemblies Table	73
8.3 Shim Options.....	74
8.4 Modules.....	75
8.4.1 APEX Slot Die Module, for Festo solenoid valve.....	75
8.4.2 APEX Slot Die Module, with MAC solenoid valve.....	76
8.4.3 APEX Slot Die Module, with MAC solenoid valve and air tubes.....	77
8.5 Festo Solenoid Assemblies, PN 115055 & 115056	78
Chapter 9 Engineering Drawings & Schematics.....	79
9.1 Pin Connectors & Electrical Schematics.....	79
9.2 DynaControl/Dynamini or PLC (Platinum RTD) Control Scheme, PN 103117	79
9.3 Upgrade (Nickel RTD) Control Scheme PN 104551	79
Chapter 10 Appendix.....	81
10.1 Solenoid Valve Configurations, Schematics & Setup	81
10.1.1 Filter/ Regulator Installation Notes.....	81
10.1.2 Section 1, Solenoid Valves PN 100054 (24 VAC) & PN 106193 (110 VAC).....	82
10.1.3 Section 2, Solenoid Valve PN 811506 (240 VAC).....	83
10.1.4 Section 3, High-Speed Solenoid Valve PN 113350 (24 VDC).....	84

10.1.5 Section 4, Air Control Kit PN 100055, Component Illustration	85
10.1.6 Section 4, Air Control Kit PN 113343, Component Illustration	86
Manual Revisions	87

Chapter 1

Declaration of Incorporation / Conformity

Declaration of incorporation

according to the EU Machinery Directive 2006/42/EG, Annex II, 1.B
for partly completed machinery

Manufacturer:

ITW Dynatec,
31 Volunteer Drive
37075 Hendersonville, TN

Person residing within the Community authorised to compile the relevant technical documentation:

Andreas Pahl
ITW Dynatec GmbH,
Industriestraße 28
40822 Mettmann

Description and identification of the partly completed machinery:

Product / Article: EQC Slot Die Applicator
Serial no: _____
Machine number: _____
Project number: EQC
Project name: EQC Slot Die Applicator
Function: Delivery of hot melt adhesive to substrates

It is declared that the following essential requirements of the Machinery Directive 2006/42/EG have been fulfilled:

1.3.2.; 1.3.7.; 1.5.1.; 1.5.16.; 1.5.2.; 1.5.5.; 1.5.6.; 1.5.7.; 1.6.3.

It is also declared that the relevant technical documentation has been compiled in accordance with part B of Annex VII.

It is expressly declared that the partly completed machinery fulfils all relevant provisions of the following EU Directives:

2004/108/EG:2004-12-15 (Electromagnetic compatibility) Directive 2004/108/EC of the European Parliament and of the Council of 15 December 2004 on the approximation of the laws of the Member States relating to electromagnetic compatibility and repealing Directive 89/336/EEC
2006/95/EG:2006-12-12 (Voltage limits) Directive of the European Parliament and of the Council of 12 December 2006 on the harmonisation of the laws of Member States relating to electrical equipment designed for use within certain voltage limits (codified version)

Reference to the harmonized standards used:

EN ISO 14121-1:2007 Safety of machinery - Risk assessment - Part 1: Principles (ISO 14121-1:2007)
EN 60204-1:2006-06 Safety of machinery - Electrical equipment of machines - Part 1: General requirements
EN 349:1993 + A1 Safety of machinery - Minimum gaps to avoid crushing of parts of the human body
EN ISO 12100-1/A1:2009 Safety of machinery - Basic concepts, general principles for design - Part 1: Basic terminology, methodology
EN ISO 12100-2:2003/A1 Safety of machinery - Basic concepts, general principles for design - Part 2: Technical principles
EN ISO 13850:2008 Safety of machinery - Emergency stop - Principles for design (ISO 13850:2006)


The manufacturer or his authorised representative undertake to transmit, in response to a reasoned request by the national authorities, relevant information on the partly completed machinery. This transmission takes place:

This does not affect the intellectual property rights!

Important note! The partly completed machinery may be put into service only if it was determined, where appropriate, that the machinery into which the partly completed machinery is to be installed meets the provisions of this Directive.

Hendersonville, TN, 2012.10.11

Place, date


Signature
Judson Broome
General Manager

This page intentionally left blank.

Chapter 2

Safety Instructions

2.1 General Considerations



- All operators and service personnel must read and understand this manual before operating or servicing equipment.
- All maintenance and service on this equipment must be performed by trained technicians.



Read and adhere to the manual!








1. Read and follow these instructions.
Failure to do this could result in severe personal injury or death.
2. Keep the binding rules for accident prevention valid for your country and the place of installation. Also keep the approved qualified technical rules for safety-conscious and professional work.
3. Additional safety instructions and/ or symbols are located throughout this manual. They serve to warn maintenance personnel and operators about potentially hazardous situations.
4. Inspect the machine for unsafe conditions daily and replace all worn or defective parts.
5. Keep work area uncluttered and well lit. Remove all material or things not needed for the production from the workspace of the equipment!
6. All covers and guards must be in place before operating this equipment.
7. Subject to technical modifications without notice!
8. To ensure proper operation of the equipment, use specified electrical and/ or air supply sources.
9. Do not attempt to alter the design of the equipment unless written approval is received from ITW Dynatec.
10. Keep all manuals readily accessible at all times and refer to it often for the best performance from your equipment.

2.2 Warning Labels

1. Read and obey all of the warning labels, signs and caution statements on the equipment.
2. Do not remove or deface any of the warning labels, signs and caution statements on the equipment.
3. Replace any warning labels, signs and caution statements which have been removed or defaced. Replacements are available from ITW Dynatec.






2.3 Safety Symbols in this Manual

Mandatory signs



	General mandatory sign		Wear foot guard!
	Read and adhere to the documentation!		Wear protective gloves!
	Switch the unit voltage-free before working! Main switch OFF!		Wear protective clothing!
	Wear headgear, protective goggles and ear protection!		

Warning signs

NOTE: The dangers and risks exist if the corresponding instructions are not heeded and the precautionary measures are not taken!

	Caution, danger spot! This sign points to possible dangers for life and physical condition or to possible risks for machine and material or to possible risks for environment. The word “DANGER” in addition with this points to possible dangers of life The words “WARNING” and “CAUTION” in addition with this sign point to possible risks of injury. The word “ADVICE” in addition with this sign points to possible risks for machine, material or environment.		Danger, high voltage! This sign points to possible dangers for life and physical condition caused by electricity. Risk of injury, mortal danger!
			Caution, hot surface! This sign points to possible risks of burns. Risk of Burns!
			Caution, high pressure! This sign points to possible risks of injury caused by high pressure. Risk of injury!
			Caution, rotating rolls! This sign points to possible risks of injury caused by inrunning nip (at rolls). Risk of injury!

Prohibition signs

	Fire danger! Smoking prohibited!		Fire danger! Fire and open flames prohibited!
---	---	--	--

2.4 Safe Installation and Operation



Read and adhere to the manual!

1. Read this manual before applying electrical power to the equipment. Equipment may be damaged by incorrect electrical connections.
2. To avoid possible failure of hoses, make sure all hoses are routed to avoid kinking, tight radius turns (8" or less) and abrasive contact. Hot-melt hoses should not have prolonged contact with heat-absorbing surfaces such as cold floors or metal troughs. These heat-absorbing surfaces can alter adhesive flow and cause incorrect calibration. Hoses should never be covered with materials that prevent heat dissipation, such as insulation or sheathing. Hoses should be spaced apart from each other, not making direct contact.
3. Do not use adhesive that is dirty or that may be chemically contaminated. Doing so can cause system clogging and pump damage.
4. When adhesive hand-held applicators or other movable applicators are used, never point them at yourself or at any other person. Never leave a hand-held applicator's trigger unlocked when not actually in use.
5. Do not operate the hopper or other system components without adhesive for more than 15 minutes if the temperature is 150 degrees C (300 degrees F) or more. To do so will cause charring of the residual adhesive.
6. Never activate the heads, hand-held applicators and/ or other application devices until the adhesive's temperature is within the operating range. Severe damage could result to internal parts and seals.
7. Never attempt to lift or move the unit when there is molten adhesive in the system.
8. In case of an emergency or exceptional incident, press the emergency stop button in order to stop the unit quickly.
9. Use the unit only as it is intended to.
10. Never let the unit run unattended.
11. Operate the unit only in a faultless and fully functional condition. Check and make sure that all safety devices work in proper form!



Smoking, fire and open flames prohibited! Fire danger!

Make absolutely sure that there is no smoking and no fire being lit in the work area!

2.5 Explosion/ Fire Hazard

1. Never operate this unit in an explosive environment.
2. Use cleaning compounds recommended by ITW Dynatec or your adhesive supplier only.
3. Flash points of cleaning compounds vary according to their composition, so consult with your supplier to determine the maximum heating temperatures and safety precautions.

2.6 Use of PUR (Polyurethane) Adhesives

1. PUR adhesives emit fumes (MDI and TDI) that can be dangerous to anyone exposed to them. These fumes cannot be detected by the sense of smell. ITW Dynatec strongly recommends that a power-vented exhaust hood or system be installed over any PUR system.
2. Consult with your adhesive manufacturer for specifics about required ventilation.



CAUTION

Because of the nature of PUR adhesives to strongly bond in the presence of moisture, care must be taken to prevent them from curing inside ITW Dynatec equipment.

If PUR adhesive solidifies in a unit, the unit must be replaced. Always purge old PUR adhesive from the system per your adhesive manufacturer's instructions and time table.

ALLOWING PUR ADHESIVE TO CURE IN A UNIT OR ITS COMPONENTS VOIDS ITW DYNATEC'S WARRANTY.

2.7 Eye Protection & Protective Clothing



WARNING

Eye Protection & Protective Clothing Required

1. It is very important that you PROTECT YOUR EYES when working around hot melt adhesive equipment!
2. Wear a face shield conforming to ANSI Z87.1 or safety glasses with side shields which conform to ANSI Z87.1 or EN166.
3. Failure to wear a face shield or safety glasses could result in severe eye injury.
4. It is important to protect yourself from potential burns when working around hot melt adhesive equipment.
5. Wear heat-resistant protective gloves and long-sleeved, protective clothing to prevent burns that could result from contact with hot material or hot components.
6. Always wear steel-reinforced safety shoes.

2.8 Electrical



DANGER HIGH VOLTAGE

1. Dangerous voltages exist at several points in this equipment. To avoid personal injury, do not touch exposed connections and components while input power is on.
2. Disconnect, lockout and tag external electrical power before removing protective panels.
3. A secure connection to a reliable earth ground is essential for safe operation.
4. An electrical disconnect switch with lockout capability must be provided in the line ahead of the unit. Wiring used to supply electrical power should be installed by a qualified electrician.
5. Notify the maintenance personnel immediately, if cables are damaged. Provide for exchanging the defective components immediately.

2.9 Lockout/ Tagout



Switch the unit voltage-free before working! Main switch OFF!

1. Follow OSHA 1910.147 (Lockout/ Tagout Regulation) for equipment's lockout procedures and other important lockout/tagout guidelines.
2. Be familiar with all lockout sources on the equipment.
3. Even after the equipment has been locked out, there may be stored energy in the application system, particularly in the capacitors within the panel box. To ensure that all stored energy is relieved, wait at least one minute after removing power before servicing electrical capacitors.

2.10 High Temperatures



WARNING HOT SURFACE

1. Severe burns can occur if unprotected skin comes in contact with molten adhesive or hot application system parts.
2. Face shields (preferred) or safety glasses (for minimum protection), heat-resistant protective gloves and long-sleeved clothing must be worn whenever working with or around adhesive application systems.

2.11 High Pressure



WARNING HIGH PRESSURE PRESENT

1. To avoid personal injury, do not operate the equipment without all covers, panels and safety guards properly installed.
2. To prevent serious injury from molten adhesive under pressure when servicing the equipment, disengage the pumps and relieve the adhesive system's hydraulic pressure (i.e. trigger the heads, hand-held applicators, and/or other application devices into a waste container) before opening any hydraulic fittings or connections.
3. IMPORTANT NOTE: Even when a system's pressure gauge reads "0" psi, residual pressure and trapped air can remain within it causing hot adhesive and pressure to escape without warning when a filter cap or a hose or hydraulic connection is loosened or removed. For this reason, always wear eye protection and protective clothing.
4. Either of the two High Pressure symbols shown may be used on ITW Dynatec equipment.
5. Keep the given operating pressure.
6. Notify the maintenance personnel immediately, if hoses or components are damaged. Provide for exchanging the defective components immediately.

2.12 Protective Covers



WARNING DO NOT OPERATE WITHOUT GUARDS IN PLACE

1. Keep all guards in place!
2. To avoid personal injury, do not operate the application system without all covers, panels and safety guards properly installed.
3. Never get your extremities and/or objects into the danger area of the unit. Keep your hands away from running parts of the unit (pumps, motors, rolls or others).

2.13 Servicing, maintenance

1. Only trained and qualified personnel are to operate and service this equipment.
2. Before any service work disconnect the external power supply and the pressure air supply!
3. Never service or clean equipment while it is in motion. Shut off the equipment and lock out all input power at the source before attempting any maintenance.
4. Follow the maintenance and service instructions in the manual.
5. Keep the maintenance rates given in this documentation!
6. Any defects in the equipment that impact safe operation have to be repaired immediately.
7. Check screws that have been loosened during the repair or maintenance, if they are tight again.
8. Replace the air hoses in preventive maintenance regularly, even if they have got no viewable damages! Adhere to the manufacturers' instructions!
9. Never clean control cabinets or other houses of electrical equipment with a jet of water!
10. Adhere to the current safety data sheet of the manufacturer when using hazardous materials (cleaning agents, etc.)!

2.14 Cleaning Recommendation

- Filters are disposable and need to be replaced regularly. DO NOT boil in mineral oil, solvents or water; the sealant used in filter assembly may become brittle and very likely disintegrate when boiled.
- When cleaning other components in mineral oil, remove all non-metallic items (O-rings, seals, filter cartridge, etc.) away from chemicals before components are subjected to hot mineral oil cleaning.
- If there is not a specific rebuild kit available or directions on how to clean a part, please treat it as a replacement item and do not attempt to clean/rebuild.

2.15 Secure transport

1. Examine the entire unit immediately after receipt, if it has been delivered in perfect condition.
2. Let damages in transit certify by the carrier and announce them immediately to ITW Dynatec.
3. Use only lifting devices that are suitable for the weight and the dimensions of the equipment (see drawing of the equipment).
4. The unit has to be transported upright and horizontally!
5. The unit has to cool down to room temperature before packaged and transported.

2.16 Treatment for Burns from Hot Melt Adhesives

Measures after being burned:

1. Burns caused by hot melt adhesive must be treated at a burn center. Provide the burn center's staff a copy of the adhesive's M.S.D.S. to expedite treatment.
2. Cool burnt parts immediately!
3. Do not remove adhesive forcibly from the skin!
4. Care should be used when working with hot melt adhesives in the molten state. Because they rapidly solidify, they present a unique hazard. Even when first solidified, they are still hot and can cause severe burns.
5. When working near a hot melt application system, always wear safety shoes, heat-resistant protective gloves, safety goggles and protective clothes that cover all vulnerable parts of the body.
6. Always have first-aid information and supplies available.
7. Call a physician and/or an emergency medical technician immediately. Let the burns medicate by a medic immediately.

2.17 Measures in case of fire

1. Please heed that not covered hot parts of the engine and molten hot melt may cause heavy burns. Risk of burns!
2. Work very carefully with molten hot melt. Keep in mind, that already jelled hot melt can be very hot, too.
3. When working near a hot melt application system, always wear safety shoes, heat-resistant protective gloves, safety goggles and protective clothes that cover all vulnerable parts of the body!

Measures in case of fire:

Wear safety shoes, heat-resistant protective gloves, safety goggles and protective clothes that cover all vulnerable parts of the body.

Firefighting - burning hot melt:

Please keep attention to the safety data sheet given by the adhesive manufacturer.



EXTINGUISH FIRE

Appropriate extinguishing agents:

Foam extinguisher, Dry powder, Spray, Carbon dioxide (CO₂), Dry sand.

For safety reasons not appropriate extinguishing agents: None.

Firefighting - burning electrical equipment:

Appropriate extinguishing agents:

Carbon dioxide (CO₂), Dry powder.

2.18 Keep attention to environmental protection standards



1. When working on or with the unit, the legal obligations for waste avoidance and the duly recycling / disposals have to be fulfilled.
2. Keep attention, that during installations, repairs or maintenance matters hazardous to water, like adhesive / adhesive scrap, lubricating grease or oil, hydraulic oil, coolant and cleaner containing solvent do not pollute the ground or get into the canalization!
3. These matters have to be caught, kept, transported and disposed in appropriate reservoirs!
4. Dispose these matters according to the international, national and regional regulations.

Chapter 3

Description and Technical Specs

3.1 Applicable Safety Regulations

3.1.1 Intended Use

The Equity-C (Continuous) Slot Die Applicator may be used only to apply suitable materials, e.g. adhesives. When in doubt, seek permission from ITW Dynatec.



If the Applicator is not used in accordance with this regulation, a safe operation cannot be guaranteed.

The operator - and not ITW Dynatec - is liable for all personal injury or property damages resulting from unintended use!



Intended use includes, that you

- read this documentation,
- heed all given warnings and safety instructions, and
- do all maintenance within the given maintenance rates.

Any other use is considered to be unintended.

3.1.2 Unintended Use, Examples

The Equity-C Slot Die Applicator may not be used under the following conditions:

- In defective condition.
- In a potentially explosive atmosphere.
- With unsuitable operating/processing materials.
- When the values stated under Specifications are not complied with.

The Equity-C Slot Die Applicator may not be used to process the following materials:

- Toxic, explosive and easily flammable materials.
- Erosive and corrosive materials.
- Food products.

3.1.3 Residual Risks

In the design of the Equity-C Slot Die Applicator, every measure was taken to protect personnel from potential danger. However, some residual risks cannot be avoided.

Personnel should be aware of the following:



- Risk of burns from hot material.
- Risk of burns from hot Applicator's components.
- Risk of burns when conducting maintenance and repair work for which the system must be heated up.



- Risk of burns when attaching and removing heated hoses.
- Material fumes can be hazardous. Avoid inhalation. If necessary, exhaust material vapors and/or provide sufficient ventilation of the location of the system.
- Risk of pinching parts of the body at running parts of the Adhesive Supply Unit (pumps, motors, rolls or others).
- The safety valves may malfunction due to hardened or charred material.

3.1.4 Technical changes

Any kind of technical changes having impact to the security or the operational liability of the system should only be done by written agreement of ITW Dynatec. Suchlike changes made without given a corresponding written agreement will lead to immediate exclusion of liability granted by ITW Dynatec for all direct and indirect subsequent damages.

3.1.5 Using foreign components

ITW Dynatec takes no responsibility for consequential damages caused by using foreign components or controllers that have not been provided or installed by ITW Dynatec.

ITW Dynatec does not guarantee that foreign components or controllers used by the operating company are compatible to the ITW Dynatec-system.

3.1.6 Start-up operation

We recommend asking for an ITW Dynatec-service technician for the start-up operation, to ensure a functioning system. Let yourself and the people working with or working on the system be introduced to the system on this occasion.

ITW Dynatec takes no responsibility for damages or faults caused by any untrained personal.

3.2 Description Equity-C Slot Die Applicator

3.2.1 Description


ITW Dynatec's Equity-C (Continuous) Slot Die Applicators are continuous adhesive application heads with application width ranging from 100mm to 900mm (4" to 36") and featuring good cross web distribution of adhesive, quick-change nozzles and no-adjust/easy-cut shims.

These heads are constructed by combining 100mm or 200mm modular segments horizontally using internal connectors. Optional heated, 25mm spacer(s), placed at the ends of the applicator gives further head-width versatility (spacers not available on 900mm head).

One or multiple filter manifolds, containing integrated filter baskets designed to prevent particulate matter from obstructing adhesive flow, serve the applicator. Replaceable heater cartridges are controlled by RTD sensors. Control zones can be isolated electronically flexible applicator segments, if desired. The heads may be configured for Dynatec's DynaControl or PLC controls, as well as competitive upgrade schemes.


One application module is mounted onto each 100mm of applicator length. A piston inside the module is pneumatically triggered by a tube-mounted solenoid, allowing adhesive to flow through a valve within the module. The rate of adhesive flow from the applicator is determined by the adhesive flow applied by the ASU's gear pump or by applied pressure (piston pump). Shim thickness can be chosen in relation to the quantity of glue to work in a perfect pressure area.

The slot die assembly spans the entire applicator. Heaters are spaced every 50mm to supply equal heat distribution. The nonadjustable die lips are ground as matched pairs and their easy-cut shims are perforated to make short, accurate work of shim cutting.



Equity-C Slot Die Applicator (200mm segment shown)

3.2.3 Model Designation Guide for Equity-C Applicator



Notes:

* If this option is selected, hose inlets are required.

** If more than one pressure zone is selected, plug assembly PN 112261 must be used to create separate zones.

*** Design and part numbers "to be designed"

3.3 Solenoid Air Programs

On the Equity-C applicators, solenoids supply the air pressure which activates each adhesive module.


A solenoid air program describes the number of modules activated by each individual solenoid on an applicator. Equity-C slot die applicators are all single air-programmed solenoids. Therefore, an applicator with one module/ solenoid has one solenoid air program, an applicator with two modules/ solenoids has two solenoid air programs, etc.

3.4 Standard Configurations


The following diagrams show the standard configurations of the Equity-C line of slot die applicators. Illustrated are the standard placement of applicator segments, modules, filter manifolds, wattage and electrical connections.

Note: when adding 50mm spacer kit add 200 Watts.


100mm 400W




200mm 800W



300mm 1200W




400mm 1600W




500mm 2000W

(may have two hose filter blocks)




600mm 2400W

Note: when adding 50mm spacer kit add 200 Watts and additional cable assy.




650mm 2800W


Note: when adding 50mm spacer kit add 200 Watts and additional cable assy.




700mm 2800W



800mm 3200W




900mm 3600W



3.5 Dimensions


3.5.1 Equity-C 100mm

Note: Application width can be increased by 50mm when using a spacer kit.




3.5.2 Equity-C 200mm

Note: Application width can be increased by 50mm when using a spacer kit.




3.5.3 Equity-C 300mm

Note: Application width can be increased by 50mm when using a spacer kit.




3.5.4 Equity-C 400mm

Note: Application width can be increased by 50mm when using a spacer kit.




3.5.5 Equity-C 500mm

Note: Application width can be increased by 50mm when using a spacer kit.




3.5.6 Equity-C 600mm

Note: Application width can be increased by 50mm when using a spacer kit.




3.5.7 Equity-C 700mm

Note: Application width can be increased by 50mm when using a spacer kit.





3.5.8 Equity-C 800mm

Note: Application width can be increased by 50mm when using a spacer kit.



3.5.9 Equity-C 900mm

Note: Application width can be increased by 50mm when using a spacer kit.



Chapter 4

Installation & Start-up Operation



CAUTION

- Before installation and start-up, please read this documentation carefully.
- Pay attention to all the installation and connecting advices.
- Heed all safety instructions mentioned in chapter 2.

4.1 Conditions for installation and mounting

Place requirement

Install the Equity-C Applicator in the machine so that the operator is able to work on it from all sides, for e.g. for adjusting, preparing, maintaining, repairing, cleaning, etc. See drawing of the unit for admeasurements.

Mounting and alignment

- The complete unit has to be set up on solid, stable and flat ground.
- The alignment in height of the complete system has to be considered.
- The alignment of the machine has to be considered.

Electrical connection

- Necessary electrical connection has to be provided. See electrical schematics.
- Never connect or disconnect plug-and-socket connections under load!
- The manifold's incoming electrical power and temperature control is supplied through the flexible cable exiting the adhesive supply hose cuff. The applicator has a circular, plastic connector which mates with the connector attached to this cable.

Pneumatic connection



- In any case the air has to be clean and dry! See advice in chapter 4.3 "Quality of compressed air".
- Incoming (operating) air is supplied through a solenoid valve. It is controlled by a four-way solenoid valve and should be separately regulated and maintained at a pressure 4.1 to 6.9 bar (60 to 100 psi). Head air inlet ports are 1/8 NPT threads.
- Please heed that units with high air demand may not be used at the same time with the same air supply.



ADVICES

- Check all screw connections at the unit and retighten if necessary.
- Lay the cables and heated hoses so that no risk or least possible risk of stumbling occurs.

4.2 Installation



CAUTION

- All work on or with this unit is only permitted for skilled personnel!
- Pay attention to the electrical schematics!
- Clean and dry air to the applicator solenoids is required.
- All motors have to be attached according to the data sheet of the manufacturer.
- All heating elements have to be mounted and operated secured and according to the valid regulations.



WARNING

- Risk of burns and risk of injury!
- While installing the Applicator, use an appropriate protection device to avoid unintended contact with heated parts and with spilling out Hotmelt. The protection device has to prevent also the operator against not reaching into the adhesive application and against injuring.



NOTE

- Air lines and fittings must be capable of withstanding temperatures up to 218°C (425°F).
- Applicator control solenoid valves may be controlled by timers or limit switches which sense the position of the package or object to which adhesive is being applied. Switches should be mounted on moveable brackets to provide adjustment for proper location of adhesive application.


Typical installation for Equity-C Applicator:

1. Install the Applicator on the machine at the foreseen place.
The applicator should be supported from brackets that permit lateral and vertical adjustments. Mount the applicator on bracketry using the M8 screws and insulators provided. Allow access to the (optional) filter, if installed. Be sure that the modules' "weep" holes are visible for periodic inspection.

Off-roll Installation


Notes on Proper Off-roll Installation:

- Support the web (as the two rollers are supporting it in the illustration below) within a few inches of each side of the slot nozzle.
- Contact must be made no more than $\pm 5^\circ$ from the vertical (see two lower illustrations).



- Before making the adhesive connection to the applicator, align the adhesive supply hose with its electrical connector oriented in relation to the electrical connector on the top of the applicator.

Connect the swivel fitting of the hot melt hose to the adapter on the manifold (or the optional filter block), using any of the inlet ports located on the sides or back of the block. When tightening the hose fitting, hold the hose cuff to prevent the hose core from rotating.



Heed the following for the installation of the heated hoses:

- Heated hoses may be damaged by overheating, if they are laid faulty.
- Make your electrical hose connections at the numbered connects on the left side of the cover.
- Route hoses so that there is at least an 8-inch (20cm) radius at any bend. Do not hang hoses without proper support.
- Do not crimp, clamp, squeeze or tie hoses.
- The hose adhesive ports are located at the bottom of the filter block, to the right of the electrical connections.
- There are 5 ports for the use of up to 4 hoses and for the (optional) adhesive pressure gauge. When making hose connections, use the numbered connections and ports accordingly; i.e. make your hookup for hose/head #1 to electrical connection #1 and adhesive port #1, hose/ head #2 to electrical connection #2 and adhesive port #2, etc.

- Make the electrical connection as follows:
Make the connection from the hose to the applicator by connecting the female connector of the hose to the male connector of the applicator.
Connect all cables of the equipment components according to the electrical schematics (e.g. ASU, Hoses, Applicators, etc.).
- Install the air line onto the air inlet port on the solenoid valve.



CAUTION

- **Do not use lubricating oil with the air supply as applicators are lubricated at the factory and do not require lubrication when used in production. Where oil is present in the air supply, a coalescing filter (Dynatec PN 100055) must be installed between the standard air regulator/ filter and the applicator.**
- **In any case the air has to be clean and dry! See advice in chapter 4.3 "Quality of compressed air".**

- Interconnect the components with the foreseen Profibus (or EtherNet, etc.) interface cables (if applicable).

4.3 Quality of compressed Air



CAUTION

- In any case, the air has to be clean and dry!
- The min. requirement for compressed air supply to solenoids to control automatic Applicators is ISO 8573-1:2010 **class 2:4:3**. We recommend installing the ITW Dynatec's Air Control Kit PN 100055 (see Appendix).

Compressed air quality classes according to ISO 8573-1:2010 **class 2:4:3**:

ISO 8573-1: 2010	Solid particles			Mass concentration mg/m ³	Water		Oil
	0.1-0.5 µm	0.5-1 µm	1-5 µm		Vapor pressure dew point °C	Liquid g/m ³	
0	As stipulated by the equipment user, stricter requirements than class 1.						
1	≤ 20,000	≤ 400	≤ 10	-	≤ -70	-	0.01
2	≤ 400,000	≤ 6,000	≤ 100	-	≤ -40	-	0.1
3	-	≤ 90,000	≤ 1,000	-	≤ -20	-	1
4	-	-	≤ 10,000	-	≤ +3	-	5
5	-	-	≤ 100,000	-	≤ +7	-	-
6	-	-	-	≤ 5	≤ +10	-	-
7	-	-	-	5-10	-	≤ 0.5	-
8	-	-	-	-	-	0.5 - 5	-
9	-	-	-	-	-	5 - 10	-
X	-	-	-	> 10	-	> 10	> 10

4.4 Advices for the start-up operation



WARNING

Never activate the heads and/or other application devices with cold material/adhesive in them. Severe damage could result to internal parts and seals.



WARNING

Start with start-up operation only if

- the functioning of the unit is known, and
- the unit installation for start-up operation has been done according to the details given in the previous chapter. That means all unit components are operable.

Read the documentation thoroughly to avoid breakdowns caused by faulty handling.

We recommend asking for an ITW Dynatec-service technician for the start-up operation, to ensure a functioning unit. Let yourself and the people working with or working on the unit be introduced to the unit on this occasion.

ITW Dynatec takes no responsibility for damages or faults caused by any untrained personal.



Allow only skilled expert staff to do the start-up operation!

Always wear safety shoes, heat-resistant protective gloves, safety goggles and protective clothing when working on or with the unit. Risk of burns and risk of injury!



Risk of electric shocks! Risk of injury, Mortal danger!

The unit components are getting very hot during operation! Risk of burns!




The adhesive is very hot and pressurized! Risk of burns and risk of injury! At working temperature, molten adhesive could cause heavy burns. Let spilled out adhesive cool down first, before removing it!



CAUTION

During operating the unit, heed the following:

- Heed all safety instructions mentioned in chapter 2.
- Install an appropriate protection device to avoid unintended contact with heated parts and with spilling out hot adhesive. The protection device has to prevent also the operator against not reaching into the adhesive application and against injuring.
- Set the working temperatures strictly within the temperature range given by the adhesive manufacturer. Do not exceed this temperature range.
- Switch the unit off during longer production breaks.
- Switch the unit to standby during shorter production breaks.
- Avoid voltage fluctuation.
- The air supply has to be clean and dry.
- In case of an emergency or exceptional incident, press the emergency stop button in order to stop the unit quickly.

	CAUTION The unit is ready for operation, when <ul style="list-style-type: none">• all temperatures are within the tolerances,• all motors are switched on.
	Risk of stumbling on cables and heated hoses!
	Keep your hands away from running parts of the unit (pumps, motors, rolls or others).

4.5 Start-up operation, in general

This is a generic start-up and purging process:


1. Check the complete unit and the traverse paths for safety. Fix visible damages immediately.
2. Before switching the unit on, make sure that the starting unit could hurt no one!
3. Remove all material or other things not needed for the production from the workspace of the unit!

NOTE: It is advisable to check the temperature of the applicator. This can be done through the temperature readout of the adhesive supply unit. Surface temperature may be checked with a separate pyrometer and surface probe or with a dial thermometer. Turn the system power switch ON. Permit the applicator to warm up at least 15 minutes (5 minutes for module change) before reading temperature.

4. To turn the main power on, turn all main switches of the components to "ON"!
5. Set the temperatures in the controller.

Heed following advices:

- The operating temperature range is 38°C to 200°C (100°F to 390°F)
- Use only adhesives recommended by the adhesive manufacturer! Before changing from one type of adhesive to another (even within the same product line of one manufacturer), the unit has to be cleaned respectively purged to avoid possible chemical reactions.
- Set the temperatures of the particular heating zones in the controller according to the adhesive that is in use. Always keep the temperature range given by the adhesive manufacturer. Wrong temperature settings could cause the burning of the adhesive within the system and unsatisfactory adhesion.
- Before starting the production, keep the required heat-up phase of the adhesive respectively of the Melter, so that sufficient adhesive can be molten and supplied to the applicator.

	CAUTION The unit is ready for operation, when <ul style="list-style-type: none">• all temperatures are within the tolerances,• the adhesive in the tank of Melter is molten completely. Switch on the motors/pumps only if the adhesive is completely molten! Untimely start of the motors could cause the following risks:
---	--

- The pumps are not sufficiently supplied with adhesive and they intake air. The air causes foam formation within the adhesive system and reactions with PUR adhesives.
- The pumps run dry and may block.
- Solid adhesive could block the intake port. The pumps and motors may overheat and even be destroyed.

6. Adjust the adhesive pressure by the pressure regulator.
7. Place a heat resistant container under the applicator to collect the material that drains from it.



WARNING HIGH PRESSURE RISK OF BURNS AND INJURY!

- During the purging procedure, hot adhesive and oil can come out of the head under high pressure.
- The unit operates with very high temperatures and high adhesive pressure.
- Always wear safety shoes, heat-resistant protective gloves, safety goggles and protective clothing when working on or with the unit. Risk of burns and risk of injury!
- Molten adhesives at operating temperature could cause heavy burns.
- Do not touch the hot surfaces or parts without wearing heat-resistant protective gloves!

8. Start the motors/pumps of the Melter.
9. Purge the applicator of air and oil:
Turn the applicator ON electrically and pneumatically.

Manually open the solenoids using the controller or by pushing (with a small screwdriver or other tool) the purge button located on the solenoid coil.

Continue to hold in the purge button until all air and oil have drained and only adhesive flows from the module.

10. Switch off (deactivate) the module solenoids.
11. Clean the slot die from adhesive residuals.
12. Remove the heat resistant container.
13. Switch the controller to automatic mode.
14. Set the unit parameters respectively check if they are set correct.
15. Thread the material webs.









WARNING

Make sure, that the rolls are free from adhesive residuals or other contaminations before threading the material web!

Avoid collision!


In case of a collision with the rolls several parts of the coating station and of the Vector System can be destroyed!

Make sure unconditionally, that there is no mechanical contact possible between the Vector System and the rolls.


		The basic requirement for proper coating is a tight guidance of the material web.
		Varying material tension may cause wrinkles within the material web.
		Keep your hands, head, etc. away from running rolls! Limbs may be drawn in. Risk of crushing!


16. Start the unit (web material). Make sure that the material web runs even.
17. Activate the module solenoids for the adhesive application. Adhesive will be applied; the adhesive film will be formed!
18. Production is running.

Daily operation

	<p>Purge the Applicator before every start of production respectively of a shift by allowing the adhesive flows out until the adhesive film is clean and without tears.</p> <p>Then switch off the adhesive and clean the extruder lip/ die from adhesive.</p> <p>Bring the Applicator in work position and continue production.</p>
---	--

4.5 Shut Down Procedure


	<p>CAUTION! RISK OF BURNS AND INJURY!</p> <ul style="list-style-type: none">• Parts of the unit can be hot long after switching off.• Always wear heat-resistant protective gloves and safety goggles! Molten adhesives at operating temperature could cause heavy burns.• Do not touch the hot surfaces or parts without wearing heat-resistant protective gloves!
---	--

	<p>Do not switch off the controller and the main switch, if the unit has to be operated by weekly timer.</p>
---	---

Effect following steps for switching the unit off:

1. Switch all pumps respectively motors off.
2. Switch the main switch off!

Removing dirt:

	<p>Remove dirt from all unit components immediately.</p> <p>Wooden scrapers, lint-free cloth with thinner or cleaner may only be used for cleaning.</p> <p>Metallic scrapers or other tools made from steel, like knife or blades, may not be used under any circumstances.</p>
--	---

Chapter 5

Maintenance and Repair Notes

5.1 Security advices for maintenance and repair



WARNING

Never activate the heads and/or other application devices with cold material/adhesive in them. Severe damage could result to internal parts and seals.



Heed all security advices given in chapter 2.

Use only original parts from ITW Dynatec, otherwise ITW Dynatec's warranty is void!

Maintenance and repair work is only permitted for skilled personnel!

Always wear safety shoes, heat-resistant protective gloves, safety goggles and protective clothing that cover all vulnerable parts of the body while working on the heated unit! Risk of injury or heavy burns!



High Voltage! Risk of injury and mortal danger!

- All electrical connections must be made by qualified electrical personnel.
- Care must be taken to assure proper grounding prior to any disassembly.
- Lockout and tag the electrical sources as required.
- Make sure there is no electrical power on the leads you will be connecting.
- When covers are removed, high voltage sources create an electrocution hazard.
- Wear appropriate safety equipment when working with high voltage sources.



Parts and surfaces of the unit get very hot. High temperatures! Risk of heavy burns!



High adhesive temperature and adhesive pressure! Risk of injury or heavy burns!

Always assume that the system is under pressure, proceed with caution.

Keep a cool-pack, or bucket of clean water near the work area.

Place a heat-resistant catchment container/underlay under the components. Hot adhesive may come out.



CAUTION: At working temperature, molten adhesive could cause heavy burns. Let spilled out adhesive cool down first, before removing it!

CAUTION: Use only lint-free cleaning cloth and suitable cleaner for cleaning! Do not damage surfaces! Do not scratch above them with sharp-edged tools, otherwise the components will get leaky and inoperable!



WARNING: All maintenance and repair work has to be done at working temperature, except as noted otherwise. Else there is a risk of damaging the unit components!

Before any service work disconnect the external power supply and switch the unit voltage-free:

1. Switch off the main switch and the controller.
2. Disconnect the power supply respectively remove the plug / cable.
3. Guard the unit against unauthorized restarting!

**Before any service work the adhesive pressure must be relieved throughout the system. Switch the unit pressureless:**

1. Disconnect the pressure air supply.
2. Turn the pressure regulator to zero bar, if necessary. Wait approximately 1 minute until the pressure is relieved.
3. Open the applicators purge valve or open the applicator's modules by activating the solenoids to relieve any adhesive pressure.

5.1.1 Cleaning Recommendation

- Filters are disposable and need to be replaced regularly. DO NOT boil in mineral oil, solvents or water; the sealant used in filter assembly may become brittle and very likely disintegrate when boiled.
- When cleaning other components in mineral oil, remove all non-metallic items (O-rings, seals, filter cartridge, etc.) away from chemicals before components are subjected to hot mineral oil cleaning.
- If there is not a specific rebuild kit available or directions on how to clean a part, please treat it as a replacement item and do not attempt to clean/rebuild.

5.1.2 Equipment Preparation for Maintenance & Repair

- Adhesive processing equipment must be worked on while hot enough to soften any material residue within the assembly. This depends on the type of adhesive used with the equipment. This may require the system to be up to operating temperature before disassembled, to prevent damage to fasteners and components.
- Once disassembled, the individual parts may be cleaned by immersion in approved solvent. Surface deposits may be removed by lightly scrapped with a brass device or scrapper. Care must be taken not to damage sealing surfaces with sharp objects or sand paper.
- Components such as O-rings, fasteners and relief valves should be discarded and replaced by certified ITW Dynatec replacement parts.

5.1.3 Re-Assembly Procedures and General Cautions

Unless noted, the re-assembly is simply the reverse sequence of the disassembly procedures. However, the following "cautions" should be followed (whenever they apply) for proper re-assembly:



CAUTION

In general, all O-RINGS AND SEALS must be replaced whenever hot-melt equipment is re-assembled. All new O-rings must be lubricated with O-ring lube (PN N07588).

SOME FITTINGS used for adhesive on hot melt equipment have straight threads and O-ring seals. Use of thread sealant is not necessary with these parts, but the O-ring seals should be clean and lubricated. Tighten straight-threaded parts and fittings until their shoulders are firmly seated. Excessive torque may damage straight-threaded parts and the use of power wrenches is not recommended.

HOT-MELT RESIDUE must be cleaned from parts before they are re-assembled, particularly from threaded parts. As a precaution against adhesive residue preventing proper re-assembly, threaded parts must always be re-tightened at operating temperature.

5.2 Maintenance plan



CAUTION

Heed all security advices given in chapter 5.1.

Use only original parts from ITW Dynatec, otherwise ITW Dynatec’s warranty is void!

Please use only the indicated lubricants and keep the prescribed maintenance intervals. Consider in addition the enclosed regulations of manufactures.

Punctual and conscientious maintenance of the unit secures not only a trouble free function, but prevents also for expensive repair costs.

Remove all materials and tools used during the repair or maintenance from the workspace of the unit.

Place a heat-resistant catchment container/underlay under the components. Hot adhesive may come out.




Use only lint-free cleaning cloth and suitable cleaner for cleaning! Do not damage surfaces! Do not scratch above them with sharp-edged tools, otherwise the components will get leaky and inoperable!

The applicator requires no regular maintenance. Wipe the applicator clean of adhesive with a clean cloth while still hot at the end of each shift, taking care not to damage the shim. Inspect the applicator periodically as outlined in the following table.

Maintenance plan:

Operating time/ frequency	Inspection point / maintenance notes
Continuous	<ul style="list-style-type: none"> Remove dropped out adhesive and scrap adhesive and search for the cause of that, eliminate the cause.
Once a day	<ul style="list-style-type: none"> Clean the Applicator and components from dirt.
Once a week	<ul style="list-style-type: none"> Check the Slot Die for proper operation and clean the Die assembly if necessary. Check filter for clogging and replace if necessary. Check modules on Applicator if leaky and replace if necessary. (Monitor for excess adhesive flow out of “Weep holes” – small amount is normal). Check air supply connections for leaks and tighten if loose or replace if necessary. Check all hose fittings for leaks and tighten if necessary. Check the solenoid valves for proper function and replace it if necessary.
Every 3 months	<ul style="list-style-type: none"> Due to temperature differences a loosening of threads (threaded connections) is possible. Check all parts with threads, all screw fittings and fasteners for tightness and tighten them if necessary.
Once a year	<ul style="list-style-type: none"> Clean the Applicator. Complete check-up for wearing.
Every two years	<ul style="list-style-type: none"> Complete maintenance.

5.3 Module Replacement

	WARNING
	Heed all security advices given in chapter 5.1.
	Maintenance and repair work is only permitted for skilled personnel!
	Always wear safety shoes, heat-resistant protective gloves, safety goggles and protective clothing that cover all vulnerable parts of the body while working on the heated unit! Risk of injury or severe burns!
	During this procedure, hot adhesive can come out of the Applicator under high pressure.
	Components and adhesive are hot. Take every precaution to prevent the material and hot surfaces from contacting the skin.


NOTE: The stroke for standard modules is factory set to $0.3\text{mm} \pm 0.05\text{mm}$ ($0.012'' \pm 0.002''$) and for high flow modules to $0.6\text{mm} \pm 0.05\text{mm}$ ($0.012'' \pm 0.002''$).

1. The Applicator must be at operating temperature.
2. Turn the ASU's pump/ motor OFF.
3. Switch the unit pressureless. Open the applicator's modules by activating the solenoids to relieve any adhesive pressure
4. Place a heat-resistant catchment container/underlay under the Applicator. Hot adhesive may come out!
5. Remove the air fittings and solenoid valve.
6. Unscrew the 4 screws of the module and remove the module.
7. Apply O-ring lubricant (PN N07588) to the module O-rings.
8. Clean the module bore in the applicator from adhesive residues.
9. Insert the module and fasten it with the 4 screws.
10. Reconnect the solenoid valve and air fittings.

After finishing the maintenance or repair works:

- Remove all materials and tools used during the repair or maintenance from the workspace of the unit.
- Connect the compressed air supply.
- Continue production.

5.4 Replacement of the Filter in Optional Filter Block



WARNING

Heed all security advices given in chapter 5.1.


Maintenance and repair work is only permitted for skilled personnel!

Always wear safety shoes, heat-resistant protective gloves, safety goggles and protective clothing that cover all vulnerable parts of the body while working on the heated unit! Risk of injury or severe burns!

During this procedure, hot adhesive can come out of the Applicator under high pressure.

Components and adhesive are hot. Take every precaution to prevent the material and hot surfaces from contacting the skin.

1. The Applicator must be at operating temperature.
2. Turn the ASU's pump/ motor OFF.
3. Switch the unit voltage-free and pressureless.
4. Guard the unit against unauthorized restarting.
5. Place a heat-resistant catchment container/underlay under the Applicator. Hot adhesive may come out!
6. *Relieve the adhesive pressure by:*
 - a. Manually open the module(s). This is done by pushing the solenoid operator button(s) located on the back of the air solenoid coil(s).
 - b. Open the purge screw two turns. This screw is located on the back of the filter block next to the tamper-proof screw which prevents its removal.
 - c. If the ASU filter manifold is equipped with a drain, adhesive pressure may be relieved at the ASU.
7. Wearing insulated gloves, unscrew and remove the filter nut.
8. With needle nose pliers, pull the old filter basket out of the filter block.
9. Replace the O-ring on the filter nut. Apply O-ring lubricant (PN N07588) to the new O-ring.
10. Apply a coat of anti-seize to the threads of the filter nut.
11. Re-install a new filter basket and the filter nut. Tighten the filter nut until it is seated firmly, taking care not to cut the O-ring.




After finishing the maintenance or repair works:

- Remove all materials and tools used during the repair or maintenance from the workspace of the unit.
- Connect the voltage supply and the compressed air supply. Heat the unit up. Wait until all temperatures are within the tolerances and the adhesive in the hopper is molten completely.
- Continue production.

5.5 Changing, Cleaning or Cutting New Shims

The shim is sandwiched in between the front plate and intermediate plate. These three parts (shim, front plate and intermediate plate) comprise the die lip set. (Note: Shims are sold separately from the front plate and intermediate plate, which are sold as a matched set.) Shims are available from Dynatec (in packages of minimum 3 shims) in different thicknesses. It is the shim thickness, along with variations in glue application pressure, which determines the volume of glue that is applied by the slot die at any given web speed.



WARNING



Heed all security advices given in chapter 5.1.

Maintenance and repair work is only permitted for skilled personnel!

Always wear safety shoes, heat-resistant protective gloves, safety goggles and protective clothing that cover all vulnerable parts of the body while working on the heated unit! Risk of injury or severe burns!

During this procedure, hot adhesive can come out of the Applicator under high pressure.

Components and adhesive are hot. Take every precaution to prevent the material and hot surfaces from contacting the skin.

5.5.1 Disassembly of Die Lip Set (To Change or Clean Shim)


1. The Applicator must be at operating temperature.
2. Turn the ASU's pump/ motor OFF.
3. Switch the unit voltage-free and pressureless.
4. Guard the unit against unauthorized restarting.
5. Place a heat-resistant catchment container/underlay under the Applicator. Hot adhesive may come out!
6. Loosen the pressure screws approximately one revolution using a 4mm hex wrench.
7. Slide out the die lip set from the bottom side of the application head.



CAUTION

Take care not to scratch or nick the mating surfaces of the parts of die lip set during this procedure.

8. Remove the retaining screws from the rear die lip using a 4mm hex wrench.
9. Use two M6 screws in the tapped holes located next to the dowel pins to gently pry the intermediate plate from the front die lip plate.




10. Carefully disassemble the die lip set without scratching or nicking any surface.



CAUTION

Extreme care must be taken not to bend, scratch or otherwise damage the delicate shim, as this will detrimentally affect the slot die performance.

11. Remove the shim from the dowel pins, taking care not to bend the shim.



5.5.2 Cleaning a Shim

The typical shim may be cleaned by removing all adhesive. However, some PUR adhesives that have been allowed to “cure” on a shim cannot be readily removed.


To clean adhesive from a shim, use one of the following methods:

1. Wearing heat-resistant gloves, carefully heat the shim, using a hand-held heating device, in order to liquify the adhesive on the shim, then wipe clean using a clean cloth.
2. Clean with an adhesive solvent recommended by your adhesive manufacturer.

5.5.3 Cutting a New Shim

Shims cut to the same pattern, out of the same thickness or a different thickness blank shim, can be used to replace the original shim within the die lip set.

1. Obtain a Dynatec “Easy-Cut” blank shim appropriate for the maximum application width of your applicator.
2. With a water-resistant marker, mark the cutout “start” and “end” positions on the shim, corresponding to your application’s width specifications.
3. Make two straight cuts at your marked positions to the perforations of the shim.
4. Carefully bend the shim slightly forward and backward to break out the cutout portion of the shim.



5.5.4 Reassembly

Reverse the order of the disassembly instructions provided earlier in this chapter.

1. Re-assemble the three pieces of the die lip assembly.
2. Properly position the single dowel pin on top of the die lip/ distribution plate assembly into the slot die and push it completely up into the applicator body.
3. Re-tighten the pressure screws (M8 set screws) equally, in increments, using a 4mm hex wrench.
Tighten from the center screw outward to the right and left sides of the applicator until reaching a final tightening torque of 25 in.lbs. To avoid O-ring leakage, do not over-torque screws.

After finishing the maintenance or repair works:

- Remove all materials and tools used during the repair or maintenance from the workspace of the unit.
- Connect the voltage supply and the compressed air supply. Heat the unit up. Wait until all temperatures are within the tolerances and the adhesive in the hopper is molten completely.
- Continue production.

Chapter 6

Troubleshooting

6.1 Troubleshooting In General



NOTE: Please re-read all security advices given in chapter 2 before performing any troubleshooting or repair procedures.

All troubleshooting or repair procedures must be performed by qualified, trained technicians.



DANGER HIGH VOLTAGE

The Adhesive Supply Unit and Applicator use electrical power that can be life threatening and hot-melt adhesives that can cause serious burns. Only qualified persons should perform service on the ASU.



WARNING HOT SURFACE

Severe burns can occur if unprotected skin comes in contact with molten adhesive or hot application system parts.

Some of the procedures in the following Troubleshooting Guide require working near hot adhesive.

Face shields (preferred) or safety glasses (for minimum protection), heat-resistant protective gloves and long-sleeved clothing must be worn whenever working with or around adhesive application systems.

Use proper tools for handling hot melt components.



6.2 Troubleshooting Guide



NOTE: The temperatures measured on the outer surface may deviate significantly from the temperatures set and displayed. This can lead to a false conclusion (e.g. defective heating). Such a difference is normal and depends also largely on the materials used.

Preliminary Checks: Verify the following before proceeding:

- All pneumatic and electrical connections are correct.
- The ASU is supplied with power and the main power switch is ON.
- Adhesive is in the hopper and the ASU's pump is ON.
- The ASU and Applicator have sufficient air pressure.
- The temperature controller is in operation. The setpoints are correct for the application, ASU, Heated Hoses and Applicators. All components are heating properly.

Problem	Possible Cause	Solution
Module does not open.	<ol style="list-style-type: none"> 1. Temperature adjustment of head is too low. 2. Inoperative solenoid. 	<ol style="list-style-type: none"> 1. Check temperature adjustment. 2. Push the solenoid's manual button. If it opens, the problem is electrical.
No adhesive flowing out of module.	<ol style="list-style-type: none"> 1. Die assembly is clogged. 2. Filter element is dirty. 3. Module seals (O-rings) are inoperative. 4. ASU's hopper is empty. 5. Adhesive is too cold. 6. Solenoid valve is not opening. 7. Shim is too thin for the adhesive being used. 	<ol style="list-style-type: none"> 1. Clean die assembly, see instructions in Ch. 5 Maintenance. 2. Replace filter, see instructions in Ch. 5 Maintenance. 3. Check module O-rings, see instructions in this chapter: "Module Assembly Instructions". 4. Re-fill hopper. 5. Adjust temperature, see ASU manual. 6. Check solenoid valve. 7. Use a thicker shim or a different adhesive.
Hot melt is coming out of the module's "weep" holes.	<ol style="list-style-type: none"> 1. Module seals are damaged. 	<ol style="list-style-type: none"> 1. Replace module, see instructions in this chapter.

Problem	Possible Cause	Solution
Applicator does not reach operating temperature.	<ol style="list-style-type: none"> 1. Hopper temperature setpoint is too low. 2. Inoperative heater cartridge. 3. Inoperative temperature sensor. 	<ol style="list-style-type: none"> 1. Change setpoint, see ASU manual. 2. Check/ replace heater cartridge, see instructions in this chapter. 3. Check/ replace sensor, see instructions in this chapter.
Applicator is too hot.	<ol style="list-style-type: none"> 1. Applicator temperature setpoint is too high. 2. Inoperative temperature sensor. 	<ol style="list-style-type: none"> 1. Change setpoint, see ASU manual. 2. Check/ replace sensor, see instructions in this chapter
Air escapes from module.	<ol style="list-style-type: none"> 1. Inoperative piston O-ring. 2. O-rings located between module and manifold are inoperative. 	<ol style="list-style-type: none"> 1. Replace module, see instructions in this chapter. 2. Remove module from block (see instructions in this chapter: "Replacement of Module") and replace O-rings.
Application pattern is erratic.	<ol style="list-style-type: none"> 1. Adhesive pressure is too low. 2. Pattern controller's adjustment is improper. 	<ol style="list-style-type: none"> 1. <ol style="list-style-type: none"> a. <i>For units without speed control:</i> increase adhesive pressure at ASU. b. <i>For units with speed control (tach follower):</i> adjust pump speed control. 2. See pattern controller manual for proper adjustment.

6.3 Testing of Heater Cartridge or Temperature Sensor

1. Turn the ASU OFF and make sure all adhesive air pressure and the pump are turned OFF.
2. Unplug the electrical cable from the adhesive supply hose to expose the pins in the cable.

Note: Pin connectors and pinout numbers will vary depending on the control scheme of the applicator. See pages Chapter 8 for a diagram of each.

Testing Resistance of the Heater Cartridge

- a. The resistance value (Ohms) of your heater cartridge may be calculated using the formula:

$$\frac{\text{Volts}^2}{\text{Watts}} = \text{Ohms}$$

To determine wattage, see heater chart in Chapter 7.

- b. *Measurement:*
 - *For DynaControl/ PLC:* With an ohmmeter, contact pins 7 and 8 and measure resistance.
 - *For Upgrade (NI RTD):* With an ohmmeter, contact pins 1 and 2 and measure resistance.
- c. A tolerance range of $\pm 5\%$ is allowed. A heater cartridge that tests outside of this range must be replaced. Replacement instructions follow in this chapter.

Testing Resistance of the RTD Temperature Sensor


- a. The resistance value (Ohms) of your temperature sensor depends on the temperature of the sensor at the time it is being tested.
 - At 25°C (77°F), the resistance of a PT 100 (Platinum) sensor should be 110 Ohms.
 - At 25°C (77°F), the resistance of a N120 (Nickle) sensor should be 138 Ohms.
 - At 25°C (77°F), the resistance of a NiFe (Nickle Iron) sensor should be 100 Ohms.
- b. *Measurement:*
 - *For DynaControl/ PLC:* With an ohmmeter, contact pins 5 and 6 and measure resistance.
 - *For Upgrade (NI RTD):* With an ohmmeter, contact pins 3 and 5 and measure resistance.
- c. A tolerance range of $\pm 10\%$ is allowed. A sensor that tests outside of this range must be replaced. Replacement instructions follow in this chapter.

Resistance/ Voltage Temperature Tables for Temperature sensors:

PT 100 Ohms Control Option D		
Temperature		Resistance in Ohms
°F	°C	
32	0	100
50	10	104
68	20	108
86	30	112
104	40	116
122	50	119
140	60	123
158	70	127
176	80	131
194	90	135
212	100	139
230	110	142
248	120	146
268	130	150
284	140	154
302	150	157
320	160	161
338	170	165
356	180	168
374	190	172
392	200	176
410	210	180
428	220	183

Ni 120 Ohms Control Option N		
Temperature		Resistance in Ohms
°F	°C	
32	0	120
50	10	127
68	20	135
86	30	142
104	40	150
122	50	158
140	60	166
158	70	174
176	80	183
194	90	192
212	100	201
230	110	210
248	120	219
268	130	229
284	140	239
302	150	249
320	160	259
338	170	270
356	180	281
374	190	292
392	200	303
410	210	315
428	220	328

6.4 Replacement of Heater Cartridge or Sensor



ITW Dynatec has a High Temp Heater Splice Kit available (PN 102645). Each kit contains sufficient connectors and shrink tube to replace a heater cartridge (the heater is ordered separately).

1. Disconnect power to the ASU and make sure all adhesive air pressure and pumps are turned OFF.
2. Disconnect the electrical cable assembly from the hose.
3. Remove the wire access cover plate via four (100mm) or six (200mm) holding screws.
4. Pull the heater (or sensor) out of the manifold.
5. Apply a thin coat of thermal paste (PN 001V061) to the new cartridge heater (or new sensor).
6. Put new cartridge heater (or new sensor) in manifold.
If replacing heater: crimp ferrules onto heater wires and assemble to ceramic terminal block.
7. Replace access cover plate.

Chapter 7

Ordering Guide

7.1 Slot Die Head Heater Cartridges

Length of Segment/ # of Modules	Heater PN/ Qty. Heaters in Segment	Wattage of each Heater/ Total Wattage for Segment
25 mm/ 0 (ea. spacer)	803960/ 1 (ea. spacer)	200W / 400W
100 mm/ 1	803960/ 2	200W / 400W
200 mm/ 2	803960/ 4	200W / 800W

Add wattage of all segments on your applicator to determine total wattage of applicator.

7.2 RTD Temperature Sensors

Control	Part Number	Quantity	Description
DynaControl	N07958	1	PT100
Upgrade (Nor)	N07864	1	N120

7.3 Multi-bead Nozzle

A multi-bead nozzle is offered to give added capability in continuous and multi-line applications.

7.4 Extension Cable Assemblies

The following extension cable assemblies are available. These cables connect one applicator zone to the ASU. An extension cable must be provided for the control zones connections, which are not already supplied by hose connections.


Control Scheme	Part No.	Length
DCL/ PLC	103773	10'
	103774	15'
	103775	20'
	103776	25'
	105123	30'
	105147	40'
Upgrade (Ni RTD)	102706	10'
	106349	25'
	105834	40'
Upgrade (Pt RTD)	110159	2m
	110160	4m
	110162	8m
	110163	10m
Manifold only	110161	6m

7.5 Filter Kits

To simplify ordering, Filter Kits are available.

1. Option = Filter Kits with filter basket:


Filter Kit Part Number	O-ring Part Number	Filter Cap Part Number	Filter basket Part Number
-	N03812 O-ring #125	106303	102693 80 mesh,
114291	N03812 O-ring #125	106303	101247 100 mesh,
114292	N03812 O-ring #125	106303	106273 150 mesh,
-	N03812 O-ring #125	106303	109482 200 mesh,



2. Option = Filter Kits with easy-spin filter cartridge:

Filter Kit Part Number	O-ring Part Number	Filter Cap Part Number	Filter cartridge, easy-spin Part Number
116246*	N03812 O-ring #125	116244	116242 150 mesh, Spin-on M20
116245	N03812 O-ring #125	-	116242 150 mesh, Spin-on M20
116595	N03812 O-ring #125	116244	116593 200 mesh, Spin-on M20
116594	N03812 O-ring #125	-	116593 200 mesh, Spin-on M20

* PN 116246 M-20 Spin-On Filter Assembly (filter code C),



7.6 Recommended Spare Parts

Item No.	Part Number	Description	Quantity
1	001V061	Thermal Paste	1
2	108700	TFE Lubricant	1
3	See order	Filter Basket	2
4	803960	Heater, 240V/ 200W	m x 0.5*
5	N07958	RTD Sensor, Pt 100 (in cable)	1
6	810659	Module (standard)	m x 0.5*
7	N00179	O-ring 012 (in cable)	1
8	N00175	O-ring 008 (on die lips)	m
9	N03812	O-ring 125	1
10	N00183	O-ring 016	1
11	(see list in this chapter)	Shim	Min. 3

* Quantities for these items vary per the number of modules (ports) on the Applicator.
m = number of modules.

Chapter 8

Component Illustrations and Bill of Materials



WARNING

All parts must be periodically inspected and replaced if worn or broken. Failure to do this can affect equipment's operation and can result in personal injury.

This chapter contains the component illustrations (exploded-view drawings) for each assembly. These drawings are useful for finding part numbers as well as for use when maintaining or repairing the equipment.

Note: Most common nuts, bolts and fasteners can be obtained locally at your hardware store. Specialty fasteners are available by contacting ITW Dynatec's Customer Service.

8.1 Standard Equity-C Applicator and Components

8.1.1 Equity-C Applicator 100mm

Item No.	Part Number	Description	Quantity
1	111521	Plug Assembly	2
2	111504	Side Plate, Right	1
3	108081	Screw M3 x 8mm	8
4	110224	Information Plate	2
5	104229	Ferrule, 14G	4
6	107881	Terminal Block, Ceramic	1
7	111503	Side Plate Left	1
8	808411	Screw M6 x 16mm	10
9	112282	Dowel Pin	4
-	111520	Manifold Assembly, 100mm (items 11-17, 19)	1
11	111502	Manifold	1
12	805846	Screw M6 x 10mm	2
13	103470	Screw M3 x 5mm	1
14	803960	Heater, 10 x 40mm, 240V, 200W	2
15	111505	Wire Cover	1
16	107161	Screw M4 x 8mm	4
17	117242	Screw M8 x 10mm	4
18	810659	Module Assembly (MAC solenoid, not included)	1
	815093	Module Assembly (Festo solenoid, not included)	1
19	107324	Anti-seize Compound	A/R*
20	111518	Filter Block Assembly (not included in Manifold Assy.)	1-3
21	808285	Filter Block Mounting Screw M4x65mm	4
22		Cable Assembly Options (not included in Manifold Assy.)	1-3
	103467	DynaControl (DCL)	
	104528	NDSN Nickel RTD	

* see separate drawing and/or bill of material.

A/R* = As required.




Illustration: Typical Equity-C Applicator 100mm

8.1.2 Equity-C Applicator 200mm

Item No.	Part Number	Description	Quantity
1	111521	Plug Assembly	2
2	111504	Side Plate, Right	1
3	108081	Screw M3 x 8mm	8
4	110224	Information Plate	2
5	104229	Ferrule, 14G	8
6	107881	Terminal Block, Ceramic	2
7	111523	Plug Assembly, Cable Entry	1
8	111503	Side Plate Left	1
9	808411	Screw M6 x 16mm	10
10	112282	Dowel Pin	4
-	111526	Manifold Assembly, 200mm (items 12-18, 20)	1
12	111519	Manifold, 200mm	1
13	805846	Screw M6 x 10mm	2
14	103470	Screw M3 x 5mm	2
15	803960	Heater, 10 x 40mm, 240V, 200W	4
16	112283	Wire Cover	1
17	107161	Screw M4 x 8mm	6
18	117242	Screw M8 x 10mm	8
19	810659	Module Assembly (MAC solenoid, not included)	2
	815093	Module Assembly (Festo solenoid, not included)	2
20	107324	Anti-seize Compound	A/R*
21	111518	Filter Block Assembly (not included in Manifold Assy.)	1-3
22	808285	Filter Block Mounting Screw M4x65 mm	4
23		Cable Assembly Options (not included in Manifold Assy.)	1-3
	103467	DynaControl (DCL)	
	104528	NDSN Nickel RTD	

* see separate drawing and/or bill of material.

A/R* = As required.

8.1.3 Equity-C Multiple Manifold (assorted) Assemblies

Item No.	Part Number	Description	Quantity
1	111520	Manifold Assembly, 100mm	See table
2	111526	Manifold Assembly, 200mm	See table
3	101625	Fitting, Plug, 1/4 BSPP	See table
4	111521	Plug Assembly, Manifold	2
5	111504	Side Plate, Right	1
6	112299	Screw M3 x 8mm	8
7	111506	Information Plate	2
8	104229	Ferrule, 14G	See table
9	111522	Plug Assembly, Connection	See table
10	See table	Rod, Manifold Assembly	2
11	See table	Nozzle Assembly, Slot Die	1
12	107881	Terminal Block, Ceramic	See table
13	111523	Plug Assembly	See table
14	111503	Side Plate, Left	1
15	808411	Screw M6 x 16mm	10
16	808414	Lock washer M10, split (not used on 112300 or 112301)	4
17	808415	Hex nut M10 (not used on 112300 or 112301)	4
18	111282	Dowel Pin, 3mm x 8mm	See table
19	111507	Wire Assembly	See table
20	N07430	Terminal Ring, 12-16GA, Uninsulated	See table
21	107536	Screw M8 x 60mm	4
22	105060	Hex nut M8 x 1.25mm	8
23	106321	Flat washer 8.9 mm x 17mm x 1.6mm	8
24	L00006	Insulator Spacer	4
25	107326	Heat Transfer Compound	A/R*
26	001U002	Silicone Lubricant	A/R*
27	112773	Indexing Plunger	2
28	112192	Heated Spacer Assembly 25mm	See table

* see separate drawing and/or bill of material.

A/R* = As required.

Length	Head Assy.	Item 1 Qty.	Item 2 Qty.	Item 3 Qty.	Item 8 Qty.	Item 9 Qty.	Item 10	Item 11	Item 12 Qty.	Item 13 Qty.	Item 18 Qty.	Item 19 Qty.	Item 20 Qty.	Item 28 Qty.
100mm	112300	1			4			*	1		4		1	
150mm	113050	1			8		113061	*	2		8	2	1	2
200mm	112301		1		8			*	2	1	4		1	
250mm	113036	1			8		113037	*	2	1	8	2	1	2
300mm	112302	3		2	8	2	112286	*	2	2	8	2	1	
350mm	113123	3		2	12	2	113062	*	4	1	12	4	1	2
400mm	112303	2	1	2	16	2	112287	*	4	2	8	2	2	
450mm	113051	2	1	2	20	2	113063	*	4	2	12	4	2	2
500mm	112304	5		4	16	4	111510	*	4	3	12	3	2	
550mm	113144	5		4	16	4	113064	*	4	3	16	5	2	2
600mm	112305	4	1	3	16	4	111288	*	4	4	12	3	2	
650mm	113105	4	1	3	20	4	113065	*	4	4	16	5	2	2
700mm	112306	3	2	3	24	4	111289	*	6	4	12	2	3	
750mm	113154	3	2	3	28	4	113066	*	6	4	16	4	3	2
800mm	112307	2	3	3	24	4	111290	*	6	5	12	2	3	
850mm	113164	2	3	3	28	4	113067	*	6	5	16	4	3	2
900mm	112308	5	2	4	24	5	111291	*	6	6	14	4	3	

* Item 11 = see lists/drawing of Typical Standard Extruder and Eagle-Beak Style Extruder assemblies on next pages.




Illustration: Typical Equity-C Multiple Manifold (assorted) Assemblies

8.1.4 Filter Block Assembly, APEX, PN 111518

Item No.	Part Number	Description	Quantity
1	N00183	O-ring -016	1
2	N03812	O-ring -125	1
3	808285	Screw M4x65mm	4
4	110449	Filter block	1
5	106303	Cap	1
6	104852	Screw M10x12 mm cone	1
7	101833	Screw 10-12 x 1/2	1
8	101625	Fitting, Plug, 1/4 BSPP	5
9	101624	Fitting, straight, 6 JIC x 1/4 BSPP	1
10	106273	Filter basket, 150 mesh	1 / Ref.*

Ref.* = Shown for reference only. See your order for specific part numbers.




Illustration: Typical APEX Filter Block Assembly, PN 111518

8.2 Extruders (Slot Nozzles)

8.2.1 Standard Extruder Assemblies Table

Length of Applicator mm	Extruder assembly PN	Item 1 *		Item 2 *		Item 3 * #	
		Extruder	Qty	O-ring -008	Qty	Shim .006", (0.15mm)	Qty
100	112284	112352	1	N00175	4	112353	1 (3 pack)
150	113077	113071	1	N00175	4	113072	1 (3 pack)
200	112274	112275	1	N00175	8	111882	1 (3 pack)
250	113034	113028	1	N00175	8	113029	1 (3 pack)
300	112181	112276	1	N00175	12	111832	1 (3 pack)
350	113121	113115	1	N00175	12	113116	1 (3 pack)
400	112180	112277	1	N00175	16	111841	1 (3 pack)
450	113060	113054	1	N00175	16	113055	1 (3 pack)
500	111524	112278	1	N00175	20	111513	1 (3 pack)
550	113142	113136	1	N00175	20	113137	1 (3 pack)
600	112150	112279	1	N00175	24	112153	1 (3 pack)
650	113104	113098	1	N00175	24	113099	1 (3 pack)
700	112160	112280	1	N00175	28	112163	1 (3 pack)
750	113153	113147	1	N00175	28	113148	1 (3 pack)
800	112170	112281	1	N00175	32	112173	1 (3 pack)
850	113163	113157	1	N00175	32	113158	1 (3 pack)
900	112285	112360	1	N00175	36	112361	1 (3 pack)

* Items 1-3 are included in extruder assembly. See drawing on next page.

See shim list on next page for various shim thickness.

8.2.2 Eagle-Beak Style Extruder Assemblies Table

When adhesive is applied to film, a smoother, more "closed" coating is required. The following slot die assemblies, featuring a curved nozzle, are recommended for film substrates.

Length of Applicator mm	Extruder assembly PN	Item 1 *		Item 2 *		Item 3 * #	
		Extruder	Qty	O-ring -008	Qty	Shim .006", (0.15mm)	Qty
100	113176	113175	1	N00175	4	112353	1 (3 pack)
150	113180	113179	1	N00175	4	113072	1 (3 pack)
200	113184	113183	1	N00175	8	111882	1 (3 pack)
250	113188	113187	1	N00175	8	113029	1 (3 pack)
300	113192	113191	1	N00175	12	111832	1 (3 pack)
350	113196	113195	1	N00175	12	113116	1 (3 pack)
400	113200	113199	1	N00175	16	111841	1 (3 pack)
450	113204	113203	1	N00175	16	113055	1 (3 pack)
500	113208	113207	1	N00175	20	111513	1 (3 pack)
550	113212	113211	1	N00175	20	113137	1 (3 pack)
600	113216	113215	1	N00175	24	112153	1 (3 pack)
650	113220	113219	1	N00175	24	113099	1 (3 pack)
700	113224	113223	1	N00175	28	112163	1 (3 pack)
750	113228	113227	1	N00175	28	113148	1 (3 pack)
800	113232	113231	1	N00175	32	112173	1 (3 pack)
850	113234	113233	1	N00175	32	113158	1 (3 pack)
900	113238	113237	1	N00175	36	112361	1 (3 pack)

* Items 1-3 are included in extruder assembly PN. See drawing on next page.

See shim list on next page for various shim thickness.

8.3 Shim Options

Blank shims (stainless) are sold in minimum order of 3 only; optional in brass available. Applicators are factory-shipped with 0.15mm/ 0.006" shims.

Length of Applicator mm	Shim Thickness / Part Numbers				
	0.15mm/ 0.006"	0.2mm/ 0.008"	0.3mm/ 0.012"	0.4mm/ 0.016"	0.5mm/ 0.020"
100	112353	112354	112355	112356	112357
150	113072	113073	113074	113075	113076
200	111882	111883	111884	111885	111886
250	113029	113030	113031	113032	113033
300	111832	111833	111834	111835	111836
350	113116	113117	113118	113119	113120
400	111841	111842	111843	111844	111745
450	113055	113056	113057	113058	113059
500	111513	111514	111515	111516	111517
550	113137	113138	113139	113140	113141
600	112153	112154	112155	112156	112157
650	113099	113100	113101	113102	113103
700	112163	112164	112165	112166	112167
750	113148	113149	113150	113151	113152
800	112173	112174	112175	112176	112177
850	113158	113159	113160	113161	113162
900	112361	112362	112363	112364	112365




Illustration: Typical Equity-C Extruder assembly

8.4 Modules

8.4.1 APEX Slot Die Module, for Festo solenoid valve

Item No.	Part Number	Description
1	815093	APEX Slot Die Module, Stem stroke 0.3 mm, No solenoid valve




Illustration: Item 1





Illustration with solenoid


8.4.2 APEX Slot Die Module, with MAC solenoid valve

Item No.	Part Number	Description
1	110427	APEX Slot Die Module, Stem stroke 0.3 mm, with MAC Solenoid valve 24V 9.3W (PN 810028)
1	814049	APEX Slot Die Module, High-Flow, Stem stroke 0.6 mm, with MAC Solenoid valve 24V 9.3W (PN 810028) Fitting 1/8 UNI Straight Male (PN 072X529)


*Illustration: Item 1*

8.4.3 APEX Slot Die Module, with MAC solenoid valve and air tubes


Item No.	Part Number	Description
1	819214	APEX Slot Die Module, Stem stroke 0.3 mm, with 400 series MAC Solenoid valve 24V, 4,24,1/4,JB (PN 108968)
2	810821	APEX Slot Die Module, Stem stroke 0.3 mm, with MAC Solenoid valve 24VDC, 4,02,1/8,HIR (PN 100054)
3	810659	APEX Slot Die Module, Stem stroke 0.3 mm No solenoid valve



Illustrations: Item 1



Item 2




Item 3

8.5 Festo Solenoid Assemblies, PN 115055 & 115056

Item No.	Part Number	Description	Quantity
01	115055	Solenoid Valve Assembly, QC, 24V, Festo 6mm	
	115056	Solenoid Valve Assembly, QC, 24V, Festo 1/4"	
02	113350	Solenoid Valve, 4 Way, 24V, Festo MHEZ-MS1H--5/2-M7	1
03	113362	Push-in Fitting, M7x6mm Tube OD (used on PN 115055 only)	1
	113363	Push-in Fitting, M7 x 1/4 Tube OD (used on PN 115056 only)	1
04	113608	Silencer with PN 113607 Reducer	2
05	113356	Seal Ring, M7	2
06	113351	Fitting Solenoid, M7 x QC Mod Prot	2
07	N00175	O-ring, -008	2
08	*	Cable, Solenoid (not included in assembly, see below*)	1

* Available Cables:
 PN 113361 Cable, Solenoid, 24V, LED, 2.5m
 PN 114557 Cable, Solenoid, 24V, LED, 10m




Chapter 9

Engineering Drawings & Schematics


9.1 Pin Connectors & Electrical Schematics

Note: Pin connectors are viewed from the exposed end. Pins not shown on schematics are not used.

9.2 DynaControl/Dynamini or PLC (Platinum RTD) Control Scheme, PN 103117



9.3 Upgrade (Nickel RTD) Control Scheme PN 104551



This page intentionally left blank.

Chapter 10

Appendix

10.1 Solenoid Valve Configurations, Schematics & Setup

This Appendix covers the pneumatic setup of the solenoid valves used to actuate the adhesive modules. A coalescing filter/ regulator kit (PN 100055) is available to provide regulated, oil-free air to the solenoid valves. The kit also contains the necessary fittings and tubing to configure the kit for each particular solenoid valve.

Some typical solenoid valve setups are shown on the following pages. While the most commonly used solenoid valves are shown, other valves not listed here may be used if required for the particular application. In general, however, the setups shown here can be applied to any solenoid valve. If there are questions about a valve that was supplied with the applicator, and it is not shown here, consult ITW Dynatec.

Appendix is divided into sections for easy reference:

Section 1	PN 100054	24 VDC solenoid valve
	PN 106193	110 VAC solenoid valve
Section 2	PN 811506	240 VAC solenoid valve
Section 3	PN 113350	Hi-Speed (Festo) Solenoid, 24 VDC, used on:
	PN 815087	24 VDC hi-speed solenoid valve assy., 6mm inlet fitting, 2.5m
	PN 815088	24 VDC hi-speed solenoid valve assy., 1/4 inlet fitting, 2.5m
	PN 815089	24 VDC hi-speed solenoid valve assy., 6mm inlet fitting, 10m
	PN 815090	24 VDC hi-speed solenoid valve assy., 6mm inlet fitting, 10m
	PN 815091	24 VDC hi-speed solenoid valve assy., 6mm inlet fitting, no cable
Section 4	PN 100055	Air Control Kit, Component Illustration
	PN 113343	Air Control Kit, Component Illustration

10.1.1 Filter/ Regulator Installation Notes

1. Compressed air for applicator head operation should be clean, dry and oil free.
2. In general, operation of more than one applicator head from a single air control kit is not recommended, because applicator response time may be increased and synchronization may be more difficult.
3. Install the filter/ regulator so that the bowl drains are easily accessible for servicing and the regulator knob is accessible for adjustments.
4. Use a minimum of 1/4" OD tubing to make connections.
5. If air tubing is routed close to the head due to space constraints, high temperature TFE tubing should be used to avoid tubing damage.

10.1.2 Section 1, Solenoid Valves PN 100054 (24 VAC) & PN 106193 (110 VAC)

Description


Direct acting poppet valve, 4-way, 1/8 NPT ports, with non-locking recessed manual operator.

Connections

IN	Inlet
EX	Exhaust
A	Open side of module
B	Close side of module

Typical Setup

Apply full air pressure (80-90 psi) to IN port of solenoid valve. Use air control kit PN 100055, configured as shown below.



10.1.3 Section 2, Solenoid Valve PN 811506 (240 VAC)

Description


Piloted spool valve (internally piloted), 4-way, 1/8 NPT ports, with non-locking recessed manual operator.

Connections

Port 1	Inlet
Port 2	Open side of module
Port 3	Close side of module
Port 4	Exhaust
Port 5	Exhaust

Typical Setup

Apply full air pressure (80-90 psi) to Port 1 of solenoid valve.
Use air control kit PN 100055, configured as shown below.



10.1.4 Section 3, High-Speed Solenoid Valve PN 113350 (24 VDC)

Description




Direct-acting spool valve, 4-way, 24 VDC operation with M7 ports. Solenoid is configured to connect directly to the module. It is not setup for use as an in-line solenoid.

Connections

Port 1	Inlet
Port 2	Close side of module
Port 3	Exhaust
Port 4	Open side of module
Port 5	Exhaust


Typical Setup

Apply full air pressure (80-90 psi) to Port 1 of solenoid valve.




10.1.5 Section 4, Air Control Kit PN 100055, Component Illustration

Item No.	Part Number	Description	Quantity
1	N06438	Nylon Tubing, .250 Dia.	10'
2	N00318	Cable Tie, .09 x 3.62 Lg	10
3	100380	Filter Assembly	1
4		Solenoid Valve Assembly	1
5	N04264	Cable Tie Anchor	3
6	N06504	Push-in Union Tee Fitting	1
7	N06430	Male Connect Fitting	3
8	N04531	1/4 Treet T, Brass	1



10.1.6 Section 4, Air Control Kit PN 113343, Component Illustration

Item No.	Part Number	Description	Quantity
1	107804	Precision regulator 0-30 psi	1
2	072X228	Nipple, hex, 1/4 NPT	1
3	107403	Coalescing filter	1
4	072X002	Street elbow 1/4 NPT x 45°	2
5	072X040	Street elbow 1/4 NPT x 90°	4
6	N00092	Fitting 1/4 Tube x 1/4 NPT	4
7	066X028	Fitting 3/8 x 1/4 NPTF	2



Kit Assembly Instructions:

1. Apply pipe sealant to the threads of the 1/4 NPT hex nipple and reducers, connect the filter/regulator and coalescing filter as shown. Make sure the outlet port of the regulator is connected to the IN port of the coalescing filter. Remove any excess sealant.
2. Assemble the gauge and mounting bracket (supplied with regulator) to the regulator as shown.
3. Place all of the fittings in a bag. Package these items, together with the assembled filter/regulator, into a single bag or box. Use the original bubble packaging from regulator to protect the gauge.

Manual Revisions

Revision	Page / Chapter	Update Description
Rev.5.18	55	Ch.7 Filters and Controllers removed.
Rev.10.18	59	Filters, solenoid types and controller types from Model Designation Guide removed.
	71	APEX Slot Die Module, High-Flow, MAC, PN 814049 added.
Rev.7.19	57	Filter kits updated.
Rev.10.20	Ch. 8	Extruders lists updated.
Rev.11.22	Ch.8	In 100mm and 200mm Applicators, the Screw M8 x 10mm PN 112298 is replaced by 117242.
Rev.8.23	P.1	Manual language added.

ITW Dynatec Service Parts and Technical Service:

AMERICAS	EUROPE, MIDDLE EAST & AFRICA	ASIA PACIFIC	
ITW Dynatec 31 Volunteer Drive Hendersonville, TN 37075 USA Tel. +1.615.824.3634 info@itwdynatec.com service@itwdynatec.com	ITW Dynatec Industriestrasse 28 40822 Mettmann Germany Tel. +49.2104.915.0 info@itwdynatec.de service@itwdynatec.de	ITW Dynatec No.2 Anzhi Street SIP, Suzhou, 215122, China Tel. +86.512.6289.0620 info@itwdynatec.cn service@itwdynatec.cn	ITW Dynatec Tsukimura Building 5th Floor 26-11, Nishikamata 7-chome Ota-ku, Tokyo 144-0051, Japan Tel. +81.3.5703.5501 info@itwdynatec.co.jp service@itwdynatec.co.jp